SELF-SERVICE KIOSKS: INSTALLATION & ASSEMBLY INSTRUCTIONS

1. Assemble the weighted BASE and kiosk STAND
- Thread the 6 large screws provided (refer to guide) through the **BASE** and fasten to the bottom of the **STAND**
- Screw **SUPPORT BRACKET 1** to the **BASE** and **STAND** using 8 screws provided (refer to guide). Please be mindful that these small screws may break easily if excessive force is used

2. Install the BASE and STAND
- Once assembled, bolt the kiosk **BASE** to the desired installation point through the 4 pre-drilled holes*
- To ensure your safety, please make certain that the kiosk **BASE** and **STAND** are securely bolted to the ground prior to adding the kiosk **BODY**

3. Secure the kiosk BODY to the STAND
- Use two people
- Have one person support the kiosk **BODY** whilst the other person assists to guide the **BODY** onto the **STAND** via the existing mounting hooks/slots
- Once slotted into place, support the kiosk whilst fastening **SUPPORT BRACKET 2** to the kiosk **BODY** and **STAND** with 4 screws provided (refer to guide)

4. Connect the EFTPOS TERMINAL POWER CABLE

5. Secure the EFTPOS TERMINAL BRACKET to the kiosk BODY with 2 screws provided (refer to guide)
- Tightly secure the screws to prevent the EFTPOS terminal from moving
- If you require further security, M4 & M3 Security Torx Screws can be purchased and used as an alternative

6. Connect power to the kiosk and EFTPOS terminal
- Black socket = EFTPOS terminal power
- Silver socket = kiosk power

7. Turn on your kiosk and EFTPOS terminal

8. Fix the CABLE TIDY BRACKET to the kiosk BODY with 4 screws provided (refer to guide)

Congratulations! Your NewBook Self-Service Kiosk is now ready to use!

*Bolts not supplied. Suitable bolts will need to be chosen depending on the installation point surface type.

INCLUDED MATERIALS:

SUPPORT BRACKET 1 BASE TO STAND

SUPPORT BRACKET 2 STAND TO BODY

CABLE TIDY BRACKET

FRONT BACK

KIOSK STAND

STAND BOTTOM VIEW

STAND TOP VIEW

KIOSK BASE

EFTPOS TERMINAL BRACKET

KIOSK BODY

EFTPOS TERMINAL POWER CABLE

MAIN UNIT POWER SUPPLY

SCREWS #1 **SCREWS #3**

SCREWS #2 **SCREWS #4**